








ITEM NO	DESCRIPTION	a	b	c	d	e	f
5001877	Drop down joystick (R=L)	bracket (1x)	cover left (1x)	cover right (1x)	cable clips (2x)	clamp (2x)	screw (2x)
5001878	Drop down joystick covers, set		cover left (1x)	cover right (1x)	cable clips (2x)		




④



4



⑤



⑥



3

