

SPARE PART INSTRUCTION


NR. **6.2.2** NAME **Mid tray**

VERSION **1.0** DATE **03-08-2021** BY **NS**

PAGE
1 of 2


5001355
5001356
5001357
5001358
5000732
5001491
5001461

M8 = 18Nm
M6 = 10Nm
M5 = 6Nm
M4 = 4Nm



STEP 1

Hexagon cap nut low M5 (6x)



STEP 2

Screw M5x5 (4x)

SPARE PART INSTRUCTION

NR.
6.2.2

NAME
Mid tray

VERSION
1.0

DATE
03-08-2021

BY
NS

PAGE
2 of 2


M8 = 18Nm

M6 = 10Nm

M5 = 6Nm

M4 = 4Nm

STEP 3



STEP 4

- Screw M6x50 (4x)
- Washer M6 (4x)
- Lock nut M6 (4x)
- Set screw M8x6 (1x)

